

NO MERCY 5

POWDERPUFF Compacts

ALL CARS FRESH OF PRE RUN RECEIVE (4) TOTAL FIX IT PLATES. THESE FIX IT PLATES MAY BE IN SQUARE OR PARALLELOGRAM FORM. IF IN PARALLELOGRAM FROM THE PLATE MUST BE 4" TOP TO BOTTOM AND SIDE TO SIDE EXACTLY, AND THE TWO FURTHERMOST POINTS MUST BE EXACTLY 7" APART. ANYTHING GREATER THAN THESE PARAMETERS WILL NOT BE PERMITTED. You may also utilize a maximum of 2 locations of nine wire, 3 loops per location.

No car at any time will be permitted more than 4 fix it plates, 2 random locations of wire and the front bumper and rear bumper wire that is permitted.

ANY MORE THAN 4 FIX IT PLATES WILL REQUIRED TO BE CUT COMPLETELY OFF INCLUDING ALL WELD. SCARRING, WINDOWING ETC WILL NOT BE PERMITTED. WE SUGGEST THAT YOU FIX IT PRIOR TO ARRIVAL. "I DON'T WANT TO CUT INTO MY FRAME" WILL FALL ON DEAF EARS.

***** FIX IT PLATES ARE THE ONLY PLATES THAT ARE ALLOWED TO BE IN PARALLELOGRAM FORM. ALL OTHER PLATES MUST BE SQUARE OR RECTANGLE BASED ON THE RULE WRITTEN PER PLATE. EXAMPLE 4"X 4" BUMPER PLATE MUST BE SQUARE.

THE RULES BELOW ARE NOT GUIDELINES, THEY ARE STRICTLY WRITTEN TO TELL YOU WHAT YOU CAN DO. IF THE RULES DO NOT SPECIFICALLY OUTLINE THAT YOU CAN DO SOMETHING, CALL.

ALL RUST REPAIR MUST BE PRE-APPROVED WHETHER IT IS THE BODY, UNIBODY OR SUBFRAME. WE WILL ALLOW FOR REPAIRS TO RE-RUN THE CAR TO FACTORY ORIENTATION, NO FURTHER.

IF YOU ARE FOUND TO HAVE PLATED THE UNIBODY FRAME OR SUBFRAME, THIS WILL RESULT IN AN AUTOMATIC LOAD.

IF YOUR CAR DID NOT COME WITH THAT PART YOU CANNOT USE IT EVEN IT IT IS A DIRECT BOLT, UNLESS THE RULES SPECIFY IT.

NO SEDAGONS AT ANY TIME FOR ANY REASON

GENERAL RULES

1. *FWD SEDAN AND STATION WAGONS ONLY WITH A MAXIMUM WHEEL BASE OF 113"*
2. *ALL PLASTIC, POT METAL, TIN, GLASS, CARPET, INTERIOR HEADLIGHTS ETC MUST BE ENTIRELY STRIPPED AND REMOVED FROM CAR. PLEASE ALSO REMOVE DOOR HANDLES AND SPEAKERS.*

3. CARS WILL RECEIVE TWO ATTEMPTS TO PASS INSPECTION ONLY.
4. BATTERY MUST BE REMOVED FROM UNDER HOOD AND PLACED IN THE COCKPIT OF THE CAR. A BATTERY BOX IS PERMITTED BUT MUST BE TIGHTLY SECURED TO EITHER THE CAGE OR FLOORBOARD. ABSOLUTELY NO PLATIC OR WOODEN BATTERY BOXES.
5. FACTORY GAS TANK MUST BE REMOVED UNLESS BEING UTILIZED AS PRIMARY FUEL CELL. IN THIS CASE IT MUST BE IN FRONT OF REAR AXLE.
6. SPARE TIRES MUST BE REMOVED.
7. **ABSOLUTELY NO RATCHET STRAPPING FUEL CELLS OF BATTERIES. MUST BE SECURED IN A BATTERY BOX.**

SAFETY

1. FOR SAFETY TWO LOCATIONS OF NINE WIRE IN FRONT WINDOW AREA ARE REQUIRED. AS AN ALTERNATIVE YOU MAY WELD OR BOLT 2 3" STRAPS ROF TO COWEL. THESE STRAPS OR WIRE MUST STAY A MINIMUM OF 4" AWAY FROM STRUT TOWERS.
2. REAR BUMPER MAY BE WIRED ON WITH TWO LOCATIONS OF NINE WIRE THROUGH TAIL LIGHT COVER ONLY WITHIN 6 INCHES OF BUMPER. THESE WIRES CANNOT GO FROM BUMPER TO TRUNK LID.
3. FRONT BUMPER MAY HAVE 2 LOCATIONS OF NINE WIRE CORE SUPPORT TO BUMPER BUT CANNOT GO THROUGH HOOD.

DRIVETRAIN

1. WIRING HARNESES ARE PERMITTED
2. NO OIL OR TRANSMISSION COOLERS
3. ELECTRIC FANS FOR RADIATOR ARE PERMITTED
4. ALUMINIM RADIATORS ARE PERMITTED
5. CARB SWAPS ARE PERMITTED, we realize that having a wiring harness is an advantage so we are allowing the swaps. ABSOLUTELY NO carb protectors
6. **BOLT ON INDY CNC HEADER PROTECTORS OR ALIKE ARE PERMITTED. THIS PROTECTOR CAN ONLY TOUCH THE HEADER AND CANNOT STRENGTHEN THE CAR IN ANY FASHION. NO BARS OR BRACES BETWEEN HEADER GUARDS ON V6**
7. YOU MAY CHOOSE ONE ENGINE MOUNT TO MAKE SOLID. NOTHING EXCESSIVE JEFFYS FAB FARM AFTERMARKET MOUNTS ARE PERMITTED. TRANSMISSION MOUNTS MUST REMAIN STOCK.
8. AFTERMARKET HEADERS ARE PERMITTING BUT MUST RUN VERTICALLY THROUGH HOOD AND CANNOT CONTACT THE SUBFRAME.
9. AFTERMARKET SHIFTERS ARE PERMITTED. We Recommend A Jeffys Fab Far shift, THE OFFICIAL SHIFTER OF DEADMAN DERBY <https://www.jeffysfabfarm.com>
10. NO SHIFTER PROTECTORS
11. You may run an aftermarket gas pedal in order to accommodate the carb swap. Must not strengthen the car in any fashion including pressure.
12. MUST RUN THE FACTORY BRAKE PEDAL, NO EXCEPTIONS
13. SPRING RISERS ARE PERMITTED

14. MUST RUN FACTORY STEERING COLUMN. A QUICK DISCONNECT STEERING WHEEL IS PERMITTED BUT CANNOT ALTER STEERING SHAFT SLIDE OR KUCKLES.

Suspension and Steering

1. *No alterations of struts will be permitted. Struts must be direct bolt and same make.*
2. *You may run spring risers*
3. *No reinforcements of tie rods or steering rack*
4. *Must run factory steering rack*
5. **No aftermarket steering columns**
6. **NO SPINDLE SAVERS**

BODY

1. *CREASING IS PERMITTED FROM C POST BACK ON REAR QUARTER PANELS AND IS PERMITTED ON THE FRONT FENDERS AS WELL.*
2. *ALL DOORS MAY BE EITHER, WIRED IN 8 LOCATIONS (2 LOOPS OF BRAIDED WIRE), OR CHAINED IN 8 LOCATIONS WITH 3/8" CHAIN, OR WELDED WITH 2 4"x4" x1/4" PLATES PER VERTICAL DOOR SEAM, AND ONE ABOVE EACH DOOR.*
3. *DRIVERS DOOR MAY BE WELDED SOLID SEAM OR YOU MAY RUN DOOR SKIN THAT MAY EXTEND NO GREATER THAN 3" IN FRONT OF FRONT DOOR SEAM OR BEHIND REAR OF FRONT DOOR SEAM. ***IF A PASSENGER IS ON BOARD EITHER IN YOUTH DIVISION OR A TWO MAN FORMAT, THE FRONT PASSENGER DOOR WILL BE CONSIDERED A DRIVERS DOOR.*
4. *THE DECK LID ON A SEDAN OR WAGON MAY BE TUCKED IN 90 DEGREES BUT MUST REMAIN ON ITS FACTORY HINGES IN FACTORY LOCATION WITHOUT MANIPULATION.*
5. *TRUNK AND SPEAKER DECK ARE CONSIDERED ONE AND CANNOT BE DISHED OR MANIPULATED.*
6. *DECK LIDS OR TAILGATES MAY EITHER BE WIRED IN 8 LOCATIONS(2 LOOPS OF BRAIDED WIRE, 8 LOCATIONS OF 3/8" CHAIN OR WELDED WITH 6 TOTAL 4"x4" 1/4" MAX SQUARE PLATES. IF WIRING YOU MAY WELD STORE BOUGHT 1" HOLED WASHERS FOR WIRE TO GO THROUGH. WASHERS MAY NOT BE WELDED OVER A SEAM OR TO UNIBODY FRAME OR SUBFRAME. WIRING MAY GO TO SPARE TIRE AREA*
7. *SPARE TIRE AREA OR FLOOR OF TRUNK MY BE PUSHED UPWARD.*
8. *HOOD- MAY BE EITHER WIRED IN 8 SPOTS, CHAINED IN 8 LOCATIONS WITH 3/8" CHAIN OR BOLTED IN FOUR LOCATIONS. IF BOLTING YOU BE WELD 2"x2" ANGLE A MAX OF 6" LONG ON FENDER AND ON HOOD IMMEDIATE TO FENDER WITH ONE 1/2" MAX BOLT PER LOCATION.*
9. *ABSOLUTELY NO WEDGING OF BODY. QUARTER PANELS MUST BE UPRIGHT*
10. *A HOOD IS NOT REQUIRED BUT IF YOU DO NOT RUN ONE ALL TIE DOWNS ARE FORFITTED*
11. *YOU MAY HAVE A MAX OF 10 3/8" BOLTS TO CONNECT HOOD LAYERS TOGETHER . THESE BOLTS MUST ONLY BE HOOD SHEET METAL TO HOOD SHEET METAL.*
12. *ABSOLUTELY NO FENDER BOLTS*

13. *IN CORE SUPPORT AREA, EITHER ON THE FRONT OR BACK SIDE OF THE CORE SUPPORT, YOU MAY HAVE 1/8" RAD GUARD OR EXPANDED METAL. THIS RAD GUARD OR EXPANDED METAL MUST ONLY BE IN CORE SUPPORT OPENING AREA AND MUST BE A FULL INCH APART FROM THE FRAME RAILS. EXPANDED METAL OR RAD GUARD CAN ONLY BE ATTACHED IN 6 LOCATIONS WITH A MAX OF 3/8" BOLTS. THESE BOLTS CAN BE NO LONGER THAN 2".*
14. *NO FRONT OR REAR WINDOW VISORS.*

FRAME

1. **PLEASE READ CAREFULLY. AT DEADMAN WE ALLOW HARDNOSING. HARDNOSING AT DEADMAN IS DEFINED AS WELDING THE BUMPER DIRECTLY TO FRONT OF FRAME WHILE REMOVING ANY BRACKETS OR SHOCKS. HARDNOSING DOES NOT MEAN SHORTENING.**
HOWEVER IN BUMPER SWAP COMPACTS WE ALLOW SHORTENING BUT ARE SPECIFIC TO WHERE THIS MAY BE SHORTENED TO. YOU CANNOT REMOVE THE ENTIRE CRUSH BOX. YOU ARE PERMITTED TO SHORTEN ONLY TO THE FRONT EDGE OF THE FACTORY CORE SUPPORT. NO EXCEPTIONS OR ACCOMODATIONS WILL BE MADE. YOU WILL NOT BE PERMITTED TO MOVE UP CUT PLATES OR MOVE TO A HEAVIER BUILD CLASS. FRONT OF THE CORE SUPPORT NO FURTHER. THE CORE SUPPORT MUST REMAIN IN THE CAR.
2. *IF BUILDING A HONDA PLEASE CALL PRIOR TO MOUNTING THE BUMPER. WE HAVE SPECIFIC PARAMETERS ON HOW TO MOUNT THE BUMPER WITH EXTENDING THE FRAME.*
3. **** WE WILL NOT BE MEASURING THE DISTANCE BETWEEN FRONT RAILS OR BETWEEN REAR RAILS. IF DEEMED EXCESSIVE YOU WILL NOT BE PERMITTED TO RUN, CALL FIRST.**
4. *YOU MAY PRE-BEND THE REAR FRAME TO ASSIST IN ROLLING.*
5. *REAR BUMPER MUST REMAIN IN FACOTRY LOCATION ON THE FACTORY BOLTS.*
6. *NO SEAM WELDING OF CRUSH BOX OR ANYTHING ELSE ON FRAME, SUBFRAME.*

BUMPERS

1. **WE DETER YOU FROM RUNNING A TUBING BUMPER BECAUSE WE HAVE SEEN TIME AND TIME AGAIN THAT THEY RIP DOORS OPEN AND CAUSE SAFETY CONCERNS. HOWEVER, WE UNDERSTAND THAT IT MAY BE A CHEAPER OPTION FOR SOME. THEREFORE, WE HAVE IMPLIMENTED THE FOLLOWING PARAMETERS FOR TUBING BUMPERS.**
 - *MAY BE EITHER 4"X4" 1/4" MAX, OR 2"X6" X 1/4" MAX. ONE OR THE OTHER*
 - *ABSOLUTELY NO POINTS*
 - *ABSOLUTELY NO GUSSETS*

- THE WIDTH OF THESE BUMPERS CANNOT EXCEED OUTSIDE OF WHEEL TO OUTSIDE OF WHEEL.
- ON THESE TUBING BUMPERS THE ENDS MUST BE TAPERED AND CAPPED. AT MINIMUM IN A 45 DEGREE ANGLE CALL FOR CLARIFICATION.
- 2. **ANY OEM BUMPER (this is for front and back), NO LOADING INCLUDING BETWEEN SKINS. MAY BE SEAM WELDED. MARKER LIGHT HOLES MAY BE COVERED WITH 1/8" MILD STEEL.**
- 3. **SMW LIGHTS, SMW MIGHTY MINIS, DEC/ ADEPT GUAGE BUMPERS ARE PERMITTED. B AND B ADEPT STYLE WITH POINT ARE APPROVED BUT MUST HAVE A 3" MAX POINT TAPERING OVER 32" AS DO ALL FAB STYLE BUMPERS. BUMPER CANNOT EXCEED 3/16" OR 10 GUAGE STYLE AND CANNOT HAVE GUSSETS. This applies to front and rear bumpers**
- 4. **NOTHING EXTRA INSIDE THE BUMPER, NO BUMPER EXTENSIONS**

FRONT BUMPER MOUNTING

1. **PERPENDICULAR TO FRAME YOU MAY ADD A 6"x6" MAX 1/4" PLATE FOR FLUSH MOUNTING SURFACE. NOT ON THE SIDE TOP OR BOTTOM. THIS IS TO BE WELDED TO THE FRAME ONLY, NO WELDING TO CORE SUPPORT OR SUB FRAME.**
2. **ABSOLUTELY NO FACTORY SHOCKS OR BRACKETS.**
3. *******On any 1 of the four outsides of the frame (1) per rail, A 4"x4" 1/4" PLATE MAY BE WELDED TO BACK OF BUMPER AND TO UNIBODY FRAME. THIS PLATE CANNOT CONTACT SUBFRAME IN ANY FASHION.**
4. **REMINDER THAT THIS PLATE MUST BE SQUARE AND MUST TOUCH BUMPER... THIS PLATE MAY BE ROTATED BUT THE PLATE MUST TOUCH THE BUMPER.**

Rear Bumper Mounting

1. **You may use a 6"x 6" x 1/4" plate Welding in the factory bumper mounting location. The top of this plate may not be above where the factory bumper bolts on. The bumper may be welded anywhere to this 6x6 plate but ONLY TO THIS PLATE..NO OTHER ATTACHMENTS. If you wish to move your bumper up you may only do so by welding it higher on this plate.**
2. **Bumper wire- You are permitted 2 locations of wire front bumper to core support only. You are permitted 2 locations of wire rear bumper to tail light panel only.**

WHEELS AND TIRES.

1. **TIRES MAY BE DOUBLED, MAY BE FOAM FILLED OR AIR FILLED.**
2. **2" MAX LIP PROTECTORS ARE PERMITTED.**
3. **A SIMPLE VALVE STEM PROTECTOR MAY BE WELDED TO WHEEL.**
4. **V TRED, SKID STEERS ARE PERMITTED ON FRONT. NO FRONT SOLID WHEELS OR TIRES**
5. **REAR TIRES MAY BE SOLID, FOAM FILLED, OR RIM ONLY**

6. NO RUBBER TIRE GUARDS / ADDITIONAL OUTER SIDEWALL (FLAP)

CAGE

REMINDER THAT DEADMAN PERMITS AN ADDITIONAL DRIVERS SAFETY DOOR BAR THAT RUNS NO FURTHER THAT THE FURTHERMOST FORWARD POINT OF THE A POST THE BACK OF THE B POST. THIS BAR MUST BE 5" OFF THE FLOOR. THIS APPLIES TO THE PASSENGER DOOR AS WELL IF YOU ARE HAVING A PASSENGER.

ABSOLUTELY NOTHING CAN BE ON THE PASSENGER FLOORBOARD INCLUDING BATTERIES TRANS COOLERS ETC. BECAUSE WE REQUIRE THESE THINGS TO BE BEHIND THE FRONT SEATS WE UNDERSTAND THAT CAGE MOUNTING IS GOING TO REQUIRE ADDITIONAL GUSSETS OR BRACKETS. HOWEVER, NOTHING CAN BE WITHING 6 INCHES OF THE WHEEL TUB OR STRUT TOWERS NO MATTER WHAT.

1. A FOUR POINT CAGE IS PERMITTED, MEANING 2 SIDE BARS, A DASH BAR AND A REAR SEAT BAR.
2. CORNERS OF CAGE HORIZONTALLY CAN BE GUSSETED
3. NO DOWN LEGS, CAGE CANNOT COME IN CONTACT WITH THE FIREWALL IN ANY FASHION.
4. SIDE BARS MAY BE OUTSIDE OF THE A POST AND B POST BUT MUST STOP ABRUPT AT THE FURTHERMOST FORWARD POINT OF THE A POST. NO EXCEPTIONS. THE BACK OF THE SIDE BAR CANNOT EXTEND ANY CLOSER THAN 6 INCHES IN FRONT OF THE REAR STRUT TOWER OR WHEEL TUB.
5. DUE TO THE FACT WE REQUIRE FACTORY STEERING COLUMN, THE FACTORY DASH BAR MAY REMAIN.
6. HALO BAR IS PERMITTED MUST RUN STRAIGHT UP ACROSS AND DOWN AND MUST BE A MAXIMUM OF 4"X4" 1/4" MATERIAL. HALO MUST BE NO FURTHER BACK THAN THE REAR KICK PANEL AND MUST START AT THE TOP OF THE SIDE BAR. HALO MUST BE ATTACHED TO ROOF IN 2 LOCATIONS WITH 4" X 4" MAX ANGLE A MAXIMUM OF 4" LONG WITH ONE 1/2" BOLT PER ATTACHMENT. HALO MUST BE NO FURTHER BACK THAN THE CENTER OF REAR WINDOW ON 4 DOOR CARS AND 8 INCHES IN FRONT OF C POST ON 2 DOORS
7. MAX FOUR POINT CAGE MATERIAL IS 6"
8. CENTER SHIFTER BAR DASH BAR TO REAR SEAT BAR IS PERMITTED.
9. ALL CAGE COMPONENTS WITH THE EXCEPTION OF THE GAS TANK PROTECTOR MUST REMAIN 5" OFF OF FLOOR AND FIREWALL.
10. FOR MOUNTING PURPOSES OF SIDE BARS, 1 PER SIDE, AN 8X 12" 1/4" PLATE MAY BE WELDED TO B PILLAR TO MOUNT SEAT BAR. THIS PLATE MUST COMPLY WITH 5" OFF FLOOR RULE.
11. THIS CAGE MUST REMAIN AS INTERNAL COCKPIT CAGE WITH EXCEPTION OF SIDE BARS AS STATED IN RULE 4.
12. GAS TANK PROTECTORS ARE PERMITTED TO BE TIGHT TO PACKING TRAY. GTP MUST NOT EXCEED 32" WIDE AND NO TALLER THAN SPEAKER DECK FACTORY LOCATION. CANNOT EXCEED BACKWARD OVER PACKING TRAY.

2 GUSSETS MAX, YOU CHOOSE EITHER ONE PER SIDE REAR SEAT BAR TO GTP OR 1 PER SIDE GTP TO HALO. ONE OR THE OTHER. ALL GUSSETS AND CAGE MUST REMAIN 6" FROM REAR STRUT TOWERS. THE GTP CANNOT BE BUILT OVER THE PACKING TRAY AREA. GTP CAN NOT BE ANY FURTHER BACK THAN THE FRONT OF THE REAR STRUT TOWERS AT ANY POINT.

NO CAGE COMPONENTS GUSSETS OR MOUNTING BRACKETS CAN BE WITHIN 6 INCHES OF STRUT TOWERS/ WHEEL WELL.

13. NO REAR WINDOW BARS

FOR QUESTIONS AND RULE CLARIFICATION PLEASE CONTACT DEVON GERMAIN AT 905-920-2732. IF CALL IS MISSED LEAVE A MESSAGE EITHER VOICEMAIL OR TEXT WITH A CALL BACK NUMBER, THE CLASS IN QUESTION AND A GOOD TIME TO RETURN CALL. PLEASE ALLOW 24 HOURS FOR RESPONSE. DO NOT CALL NEEDING IMMEDIATE ANSWER, AS WE TRY TO ANSWER ALL CALLS BUT IT IS IMPOSSIBLE TO BE ON STAND BY 100 PERCENT OF THE TIME. AS AN ALTERNATIVE YOU MAY CALL TJ MCCULLOUGH AT 301-707-6870 ONLY IF YOU WERE NOT ABLE TO CONTACT DEVON FIRST.

THANK YOU FOR BEING THE BEST PART OF DEADMAN